

品名: ステンレス製携帯用魔法瓶

実容量: 0.58L

材質: 18-8 ステンレス鋼 (粉体塗装)、ポリプロピレン、シリコーンゴム

BPAフリー 中国製

保温効力: 80°C以上 (6時間)

保冷効力: 6℃以下 (6時間)

※保温効力とは室温20℃±2℃において製品に熱湯を入れ、湯温が95℃±1℃になった時に蓋をして6時間後に計測した湯の温度を示します。

※保冷効力とは室温 20° C± 2° Cにおいて製品に冷水を入れ、水温が 4° C± 1° Cになった時に蓋をして6時間後に計測した水の温度を示します。

※飲料物を入れる前にあらかじめ少量の熱湯 (冷水) を入れ、1~2分程度予熱 (予冷) すると保温 (保冷) 効果が上がります。

Capacity: 580ml/19oz

Materials: 18-8 Stainless steel (powder coating),

Polypropylene, Silicone

BPA Free Made in China

Keep drinks hot (80°C/176°F) for 6hours. Keep drinks cold (6°C/43°F) for 6hours.

*For maximum insulation efficiency, preheat or precool the tumbler prior to use by filling in a bit of hot/cold water for 1-2 minutes.

Designed by KINTO Japan 株式会社キントー TEL 0120-34-7830 www.kinto.co.jp

- ○本品は飲料用ボトルです ○本来の目的以外で使用しないでください ○電子レンジ、食器洗浄・乾燥機でご使用いただけません。
- ○火のそばに置かないでください ○者沸洗浄はしないでください
- ○乳幼児の手の届く所には置かないでください
- ○破損や水漏れの原因になりますので落としたり強い衝撃を与えないでください
- ○思わぬけがや事故の原因になりますので、振り回さないでください
- ○中の液体が吹きてぼれる可能性がございますので、振ったり強い振動を与えないでください ○容器が膨張し破損やけがの原因になりますのでドライアイスは入れないでください
- ○蓋を閉める際にあふれる可能性がございますので飲料物は入れすぎないようご注意 ください
- ○シリコーンパッキンを正しい向きに装着してご使用ください
- ○蓋を閉める際は水平に閉まっていることを確認してください
- ○蓋の閉め方が不充分ですと中の液体が漏れる可能性がございますので、確実に 閉まっていることを確認してください
- ○蓋を閉めた後は、製品を逆さや横向きにして漏れのないことを確認してください
- ○万が一の漏れを防ぐためにバッグなどに入れる場合は縦置きにしてください
- ○中の液体が漏れた場合に破損や故障の原因になる恐れがありますので、携帯電話、 パソコン、カメラなどの精密機器類と一緒に持ち運ばないでください
- ○本体に衝撃や振動が加わった直後に萎を聞けないでください
- ○飲み物がこぼれてものを汚したり、やけどの原因となりますので、本体を傾けた状態 で蓋を開けないでください
- ○炭酸飲料を入れた時は、蓋をしっかりと持ち、ゆっくりと回してガスを抜いてから開 栓してください
- ○飲料物が噴き出す恐れがあるので、携帯電話などの精密機器類の近くでは開栓しない でください
- ○二重構造のため手で触れる部分が熱くなくても、中の飲み物や飲み口部分が熱い場合 がございますのでやけどには充分にご注意ください
- ○飲み物が勢いよく出て、やけどなどの原因になりますので、勢い飲み物を飲むときは 本体を急に傾けずにゆっくり飲んでください
- ○車の中や直射日光の当たる場所など高温になる所には長時間放置しないでください
- ○内容物の温度が高い場合や、量が少ない場合など、ご使用状況により炭酸が抜けやす くなることがございます
- ○塩分を含むスポーツドリンクやお酢を含む飲料を入れる場合は、ご使用前に内部に 錆や傷がないかご確認いただき、ご使用後はすぐに洗浄してください
- ○錆や飲料物の腐敗の原因になりますので、中身を入れた状態で長く放置しないでください
- ○熱い飲み物を入れた状態で長時間放置すると、中身が冷えた時に内部が真空状態になり、 蓋が開かなくなる、飲料が噴き出るなど、やけどやものを汚す原因となりますのでご 注意ください
- ○万が一蓋が開かなくなった場合は、蓋部分を約50℃のお湯に1分程度浸けると開けや すくなります
- ○ステンレスの錆を予防するために汚れや水分は早めに落とし、充分に乾燥させ、他の 金属との接触を避けて収納してください
- ○錆や破損の原因になりますので水中に放置しないでください
- ○洗浄の際はクレンザーやたわしを使用しないでください
- ○錆の原因になりますので塩素系漂白剤を使用しないでください
- ○使い始めなど金属の匂いが気になる場合は、お酢大さじ2杯とぬるま湯を縁まで入れ、 30分後にすすいでください
- ○容器内部に錆のような斑点が付着した時は、ぬるま湯と約10%のクエン酸を入れ、 2-3時間後に柔らかいスポンジで洗い、充分にすすいでください

This is a tumbler for beverage.

Do not use this product for other than its intended use.

Do not use in a microwave or dishwasher.

Do not place near open flames.

Do not put in boiling water. Keep out of reach of children,

Do not drop or subject the product to strong impact as it may cause breakage or leakage.

Do not swing the product around as it may cause unexpected injuries or accidents.

Do not shake or shock the product as it may cause liquid to spill.

Do not put dry ice as it may expand and cause breakage.

Be careful not to pour too much beverage as it may overflow when

Please attach the silicone ring in the correct direction.

Please check that the lid is attached horizontally when you close it.

Close the lid tightly to prevent spills or leakage when carrying.

Please flip and rotate the product to check that there is no leakage after closing the lid.

Keep the product upright to prevent accidental spills or leakage. Do not carry with electronic devices such as cell phones, computers.

and cameras as possible leakage of the liquid may cause damage or malfunction.

Do not open the cap immediately after the bottle has been subject to shock or vibration.

Please do not open the lid while the tumbler is tilted, as it may cause the beverage to spill and stain items or potentially result in burns.

When opening the bottle with carbonated beverage inside, hold the lid firmly and open slowly.

Do not open the bottle near electronic devices such as cell phones, as the beverage may spurt out.

Please be careful not to burn yourself, as the beverage or drinking spout may be very hot even if the tumbler surface does not feel hot.

Please drink hot beverages slowly without tilting the tumbler too quickly, as the beverage may come out vigorously and cause burns.

Do not leave the product under high temperature such as in a car.

Depending on the condition of use, such as when the beverage is warm or in small quantities, the beverage may go flat more easily.

Please check the inside of the tumbler for rust or scratches before filling it with sports drinks containing salt or with other beverages containing vinegar. Please wash immediately after use.

Do not leave the product with beverage inside for long time as it may spoil or cause rust on tumbler. Please be aware that leaving a hot beverage inside the container for an

extended period may cause a vacuum to form inside when the beverage cools down; this may cause the lid to not open, the beverage to spray out, and potentially result in burns or spillage.

If the lid does not open, soak the lid in about 50°C/122°F hot water for about 1 minute to help loosen it.

Immediately wash and dry well after use, then store it away from other metals to prevent rust.

Do not leave it soaked as it may rust or break.

Wash with care. Do not use abrasive cleansers or steel wool.

Do not use chlorine bleach as it may cause rust,


To remove any noticeable metallic odors, such as upon first use, add 2 tablespoons of vinegar and warm water up to the rim and rinse after 30


When rust spots are found inside the tumbler, add warm water and citric acid in ratio of 10:1, wash with soft sponge after leaving it for 2-3 hours. and rinse well.

PARTS


シリコーンパッキンを正しい向きに装着してご使用ください

Please attach the silicone ring in the correct direction.





飲料物は入れすぎないようご注意ください Be careful not to pour too much beverage.



FEATURES

